

# Rider Customization Settings

New wireless InfoKey™ controller software allows the Segway® PT rider to set his/her speed limit and Shutdown/Timeout settings. The following instructions describe how to access these new features using your InfoKey controller. Please make sure your Segway PT is powered-off when adjusting these settings.


## Setting Speed Limits

For information about the Speed Limiter, please consult your Reference Manual.

### **WARNING**

If the Segway PT pushes the Handlebar back, stop leaning forward and slow down. Always leave a gap between yourself and the Handlebar. Failure to slow down in response to the Speed Limiter could result in risk of death or serious injuries from falls.

For your first ride, the Segway PT is set to operate exclusively with the Beginner Setting enabled. If the Turtle icon does not display, do NOT ride the Segway PT until you enable the Beginner Setting. Use the Beginner Setting and ride in areas free of obstacles and distractions until you are comfortable on your Segway PT. All new riders should use the Beginner Setting. Do NOT let new riders operate the Segway PT outside of your direct supervision unless they have read the Getting Started Manual and watched the Safety Video and have a spotter to hold the Handlebar in accordance with the instructions in the Getting Started Manual.

To modify the Speed Limits and Shutdown Timeout, the rider must first (while the Segway PT is not powered on) press the Information Display button (  ) until the odometer is displayed. Then, hold the Information Display button for about two seconds, until the display message at right is shown.

The display will alternate between the current speed setting (Beginner Setting speed limit), and the display at right.

